


**Sequence for the first working on of the tube amplifier. (STARTUP)**



**Description**  
 Normal  
 ALLARM

**For more information see as reference the technical manual in the various chapters regarding the equipment logic and working.**